

# FAME FLOORING

## Underfloor Heating Guide

All our synthetic floor coverings (Nylon and Polyester) work well, unless otherwise stated.

When fitting any of these ranges in conjunction with underfloor heating there are a number of procedures that need to be adhered to:

All floor coverings need to be acclimatised in situ for at least 48 hours. During this time the underfloor heating must be left on at room temperature, i.e., a comfortable ambient temperature of about 20°C.

It is essential that the underlay used is appropriate for underfloor heating. We recommend Ball & Young ranges, either Roma or Radiance.

If double sticking we only recommend adhesives by F Ball: Styccobond F3 for permanent bond (floor covering to underlay) and Styccobond F4O (securing the underlay to the subfloor) as these products have been tested and deemed suitable for use with underfloor heating.

**Fame Flooring B.V.**

Nylonstraat 13a  
8281 JX Genemuiden  
The Netherlands

**T** +31 38 785 8239  
**E** sales@fame-flooring.com  
**W** www.fame-flooring.com

**KvK** 85181013  
**BTW** NL 863537595 B01  
**IBAN** NL 32 ABNA 0108 8888 86